

COURSE OF MEASUREMENT ARCHITECTURES FOR CYBER-PHYSICAL SYSTEMS
MASTER DEGREE IN CONTROL SYSTEM ENGINEERING

MINI-PROJECTS

OVERVIEW

The presentation is structured as a comparison between three different mini-projects in order to describe the main differences and give, at the same time, a brief but clear description of all the projects.

Projects :

A very simple real-time
game



Measuring distances with a
ultra sound sensor



Electronic compass









SUMMARY

- Hardware set-up
- Flow charts
- Results
- Problems and improvements

HARDWARE SET-UP




HARDWARE SET-UP



FLOW CHARTS

Establish connection
&
Initialization



FLOW CHARTS

Initialization parameters:

- Enable accelerometer
- **Set sampling rate = 10 [Scan/s]**
- Random generation of the coins
- Initialize figure with coins
- Set thresholds
- Begin transmitting data from selected sensors
- Start timer



- Create a session with DAQ
- **Set sampling period = 200000 [Scan/s]** (one scan every 5 μ s)
- Set continuous acquisition mode
- Set trigger and echo channel
- Add two listener
- **Set threshold for generation of the trigger and acquisition**
- Define Callback functions






- Enable magnetic sensor and orientation sensor
- **Set sampling rate = 10 [Scan/s]**
- Begin transmitting data from selected sensors
- **Calibrate the ecompass**
- Store deviations





```
session.NotifyWhenScansQueuedBelow = 100000;  
session.NotifyWhenDataAvailableExceeds = 119999;  
signal = [zeros(1,118998) 10*ones(1,2)  
...zeros(1,1000).];
```

FLOW CHARTS - Real-Time system



FLOW CHARTS - Process






FLOW CHARTS

StartBackground: starts the operation of the session object, without blocking the MATLAB command line and other code.

The **DataAvailable** event is triggered if the number of samples stored in the circular buffer exceeds the number imposed in "NotifyWhenDataAvailableExceeds".

The **DataRequired** event is fired when you need to queue more data. This parameters can be impose by setting the "NotifyWhenScansQueuedBelow" parameter. (big enough for permits to queue the new signal)

```
session.NotifyWhenScansQueuedBelow = 100000;  
session.NotifyWhenDataAvailableExceeds =  
..119999;..
```





RESULTS

Real-time game:

- Sampling time = 10 [Scan/s]
- Tcycle is about 1 s

Measuring distances:

- Sampling time = 200000 [Scan/s]
- $\Delta T = f_s * N.W.D.A.E = 0.6 \text{ s} > \Delta T_{ELAB}$
(Callback called almost 2 times for second)

Electronic compass:

- Sampling time = 10 [Scan/s]
- Tcycle is about 0.4 s



PROBLEMS AND IMPROVEMENTS

Problems:

- Need a faster response
- Not perfectly reliable connection

Improvements:

- Speed in communication
- Implement a step incremental speed



Problems:

- Not possible to implement a finite acquisition (time for full the buffer is not enough)
- 20x sec times problem for callback call
- High level phase of the echo signal not always in the same position

Improvements:

- Tuning of the parameters



Problems:

- Not perfectly accurate (1-5° inaccuracy)
- Not perfectly reliable connection
- Small delay in displaying the GUI

Improvements:

- Speed in communication

